

**P.U.(A) 328/86**  
**FACTORIES AND MACHINERY (BUILDING OPERATIONS AND WORKS OF ENGINEERING**  
**CONSTRUCTION) (SAFETY) REGULATIONS 1986**  
**PART X - SCAFFOLDS**

---

**Regulation 80. Scaffolds supported by buildings.**

No part of a building shall be used as support for part of a scaffold unless it is sound material and sufficiently stable and of sufficient strength to afford safe support. Over-hanging eaves gutters shall not be used as such support unless they have been specially designed as walkways and are of adequate strength.